

HSM8 Speaker / Microphone Instructions

The HSM8 is a combination 70V speaker and **pre-amplified** microphone designed to be used in outdoor applications. The HSM8 is designed to directly interface with the ETS SMA1-xx for connection to DVRs, IP cameras, etc. but, can be used with other compatible equipment. Note- to prevent unwanted feedback, use this product with systems supporting PTT (push to talk) half duplex audio or full duplex audio systems using acoustic echo cancelling technology

HSM8 Microphone / Speaker Placement.

Locate the HSM8 speaker / microphone near the area of interest in the space to be monitored. If a large area is to be monitored, locate the HSM8 in the middle of the space if possible. Avoid mounting the speaker / microphone near air conditioning vents, light fixtures or electrical equipment. The HSM8 should be placed as close to the subject(s) as possible. 5 to 10 feet is ideal. The HSM8 is still usable in the range of up to 50 feet in public address applications but is dependent on the level of background noise in the area. Experimentation in the environment will determine what distances work best.

Audio Signal Cable Runs

Recommended cable is: 2 each 22 gauge, stranded, two conductor shielded cables (one for the microphone and the other for the speaker) between the HSM8 microphone / speaker and the SMA1-xx or other equipment. Keep the cable run distances under 250 feet and away from AC power sources, light fixtures and electrical equipment. *Make connections as shown in Figure 1*.

HSM8 Mounting

The HSM8 is designed to be mounted on ceilings or walls and features up/down adjustments for directional aiming. Make wire connections inside the weather tight box on the back of the HSM8and screw the lid down. Mount the speaker in a fashion that does not allow water to directly flow (from driving rain etc.) inside the junction box. Sound levels for the speaker and microphone are user adjustable on the SMA1-xx interface box.

HSM8 Speaker volume

If the volume is too loud, the power level of the HSM8-C5 speaker can be changed by moving the position of the jumper on the MSI-C5 board (inside the wiring enclosure on the rear of the Speaker housing) to a lower power position. See figure 1.

HSM8 Microphone gain

Remove the windscreen and locate the gain control as shown in the figure on the back of this page. The gain is set to mid-point at the factory. If the signal from the HSM8 is too loud, rotate this control counter clock-wise. If the signal from the HSM8 is too low, adjust this control Clockwise. Experiment with different settings until the desired audio level is achieved. See figure below.




Figure 1.

Caution

It may be against the law to install this microphone kit in certain environments. It may also be against the law to record conversations of the person(s) being monitored without their knowledge. It is the responsibility of the installation company and end-user to determine if the application of this product is legal. These laws vary from state to state. If you are not informed on these matters, consult a qualified attorney or contact the appropriate state agency. A sticker is provided with this kit for the applications where notification must be posted.

Warranty

All ETS products carry a one year parts and labor warranty. This warranty does not cover damages as a result of misuse, improper handling of the unit or exposure to extreme temperatures or moisture. At its discretion, ETS reserves the right to repair or replace this unit under the conditions of the warranty. If you experience problems with your equipment call ETS at: 505-888-3923 to obtain a return authorization number. Equipment requiring repair beyond the warranty period or units that have been damaged or are not covered under the warranty can be repaired by ETS for a minimal cost under most conditions.

by