


PCKS IP Camera Kill Switch



Apply 12vdc to PCKS terminal block to keep the camera connected to the network switch. Remove 12Vdc to disconnect the camera.

Application Diagram 1 of 1 PCKS

