


The 232-BB is an in-line break out board for tapping data signals off of a DB9 RS232 cable. Only pins 2, 3 and 5 are "broke out".

### Connections

Connect DB9 cable(s) at either or both input/output jacks. All pins of the DB9s are connected 1-1...9-9 on the board. Data taps for pins 2, 3 and 5 (ground) are brought out to the connector block.

### DB9 PIN TAPS



### Warranty

All ETS products carry a one year parts and labor warranty. This warranty does not cover damages as a result of misuse, improper handling of the unit or exposure to extreme temperatures or moisture. At its discretion, ETS reserves the right to repair or replace this unit under the conditions of the warranty. If you experience problems with your equipment call ETS at: 505-888-3923 to obtain a return authorization number. Equipment requiring repair beyond the warranty period or units that have been damaged or are not covered under the warranty can be repaired by ETS for a minimal cost under most conditions.